




4

5

NOTE: DO NOT punch out inserts in the Expandability Ports until you have purchased accessories to fill.


IMPORTANT: Make sure all Expandability Ports are closed and secured.

NOTA: NO perforo los orificios para los insertos en los puertos para expansión hasta que haya comprado los accesorios para cubrirlos.

IMPORTANTE: Asegure que todos los puertos para expansión estén cerrados y seguros.

REMARQUE : Ne percez PAS les pièces d'insertion dans les ports d'agrandissement avant d'avoir acheté les accessoires pour les fixer.

IMPORTANT : Assurez-vous que tous les ports d'agrandissement soient fermés et fixés correctement.





B

Snap to secure.
Until it "clicks"

Presione para que
quede seguro.
Hasta que haga "clic"

Exercer une
pression pour fixer.
"Encliqueter"



6

TO FILL WATER BOTTLE (J).

Remove the twist off cap with rubber stopper. Fill Bottle completely by placing it under a light stream of running water. Close the bottle by pushing in the rubber stopper and twisting the cap. Turn the bottle upright and allow the vacuum to form. You may experience a few initial drips.

Place the sipper tube into the hole and pull the wire hanger in place. When refilling your Water Bottle, never squeeze it. This may cause a fracture in the plastic and make it impossible for the necessary vacuum to form.

Note: Temperature fluctuations and excessive cage vibrations sometimes cause occasional dripping. Whenever you move your CritterTrail® always remove the Water Bottle.

CÓMO USAR LA BOTELLA PARA AGUA Y EL PLATO PARA COMIDA

Para llenar la botella para agua (J), quite la tapa de plástico. Llene la botella por completo colocándola bajo un chorro pequeño de agua del grifo. Vuelva a colocar la tapa de plástico y dé vuelta la botella para agua, para permitir que se forme un vacío. Notará que caen unas pocas gotas mientras se forma el vacío. Cuando vuelva a llenar la botella de agua, nunca la apriete. Esto puede causar una rajadura en el plástico y hacer imposible que se produzca el vacío necesario.

Nota: Las variaciones de temperatura y las vibraciones excesivas de la jaula pueden ocasionar goteos de vez en cuando. Siempre saque la botella para agua cuando mueva el hábitat CritterTrail®.



UTILISATION DE LA BOMBONNE D'EAU ET DE LA MANGEOIRE

Pour remplir la bombonne d'eau (J), retirez le capuchon plastique. Remplissez la bombonne entièrement en la plaçant sous un léger filet d'eau courante. Réinstallez le capuchon plastique et retournez la bombonne d'eau à l'envers pour former un vide d'air. Au début, vous entendrez un léger « goutte à goutte » pendant que le vide d'air se forme. Lorsque vous remplissez la bombonne d'eau, ne la comprimez jamais. Ceci pourrait abîmer le plastique et empêcher la formation correcte d'un vide d'air.

Remarque: Des fluctuations de température et vibrations excessives de la cage peuvent parfois provoquer un égouttement de la bombonne. Dès lors que le Critter Trail® Habitat est déplacé, il faut systématiquement retirer la bombonne d'eau.



Cleaning • Cómo Limpiar • Nettoyage



Super Pet®
Cage Clean™



Kaytee® Bedding



KAYTEE

CritterTrail® Begin & Connect Habitat

Assembly Instructions Item #100506140



Important:

Carefully Unpack and Sort All Components on the Parts List

If your new pet home has experienced damage during shipping, please do not return your cage to the store. Our Customer Service Department is available to help with any problems.

Our Toll-Free Number (within the USA and Canada only) is 800-954-3003 or call 414-423-8544, Monday - Friday from 8:00 a.m. to 4:00 p.m. (Central Standard Time).

SAVE YOUR INSTRUCTIONS FOR FUTURE REFERENCE

Manufactured by: KAYTEE Products, Inc., Chilton, WI 53014 USA
©2013 KAYTEE Products, Inc.
For more information on bird and small animal products,
visit us at: kaytee.com

Examine each part and identify each component using the parts identification list.
Habitat Measures/Dimensions de l'habitat /El hábitat mide: 14.5" (37cm) L x 11.25" (28.5cm) W x 11" (28cm) H

CritterTrail®

Begin & Connect Habitat

Parts Identification #100506140

QTY	KEY	DESCRIPTION		COLOR
1	A	Scatter-less Base		Purple
1	B	Roof Top with Expandability Ports		Blue with Glitter
1	C	Front Wire Panel w/ Door		Green
1	D	Back Wire Panel		Green
2	E	Side Panel w/ Snap Lock		Green
4	F	Side Panel Bracket		Green
1	G	Wheel Hub		Yellow
1	H	Exercise Wheel		Yellow
2	I	Bubble Plug		Red
1	J	Water Bottle		Blue

